



GET CHOPPING

QUICK START GUIDE


In 6 quick steps you'll be on your way to enjoying something delicious!
For complete instructions for use, refer to the Instructions.




- 1.** Remove lid by turning it clockwise. Insert liner into Food Processor attachment assembly so it lies flat.




- 2.** Install the disc adapter (for julienne or shredding discs only) and the right disc for your recipe. For detailed instructions on which disc to use, refer to the Instructions.




- 3.** Install the lid by turning it counter-clockwise, being sure it locks into place.



- 4.** Insert Food Processor assembly into attachment hub on Stand Mixer, tightening knob until completely secured.



- 5.** Place a bowl or container under the food exit chute. Turn on the Stand Mixer to the appropriate speed. See the Speed Selection Guide in the Instructions.



- 6.** Use the food pusher to slowly feed items into the Food Processor assembly.